



Nº	DESCRIPCIÓN	DESCRIPTION	EBEG-70	EBEG-100	EBEG-150	EBEG-200
1	SOPORTE SEPARADOR	SEPARATOR SUPPORT	-	130100025	130100025	130100025
2	SEPARADOR INTERMEDIO	MIDDLE SEPARATOR	-	271300006	271300006	271300006
3	ENCIMERA COMPLETA	FULL WORKTOP	9E002071A	9E0004390	9E0006714	9E0006724
4	EVAPORADOR	EVAPORATOR	290100059	290100057	290100060	290100108
5	VENTILADOR CONDENSADOR	CONDENSER FAN	-	210500005	210500005	210500005
6	COMPRESOR	COMPRESSOR	210100097	210100125	210100141	210100107
7	CONDENSADOR	CONDENSER	290200014	290200007	290200007	290200006
8	GÓNDOLA DERECHA	RIGHT GONDOLA	9M002079A	9M0101962	9M006332A	9M002085A
9	REJILLA FRONTAL	FRONT GRILLE	9M0001959	9M0001959	9M0001959	9M0001959
10	GÓNDOLA IZQUIERDA	LEFT GONDOLA	9M002098A	9M0101961	9M006328A	9M002084A
11	INTERRUPTOR	SWITCH	211300017	211300017	211300017	211300017
12	TERMOSTATO	THERMOSTAT	213500005	213500005	213500005	213500005
13	REJILLA TRASERA	BACK GRILLE	-	-	-	9M0004931
14	PUERTA COMPLETA	FULL DOOR	9E002081A	9E0001965	9E0001965	9E0001965