


CD679



Machine	Explode	Code	Description
CD679 - Adjustable Salamander Grill	1	☎	Bottom plate assembly
CD679 - Adjustable Salamander Grill	2	☎	Lower heat insulation plate
CD679 - Adjustable Salamander Grill	3	AD585	Indicator light(green)
CD679 - Adjustable Salamander Grill		AA031	Indicator light(red)
CD679 - Adjustable Salamander Grill	4	AD796	Energy regulator
CD679 - Adjustable Salamander Grill	5	N243	Knob
CD679 - Adjustable Salamander Grill	6	☎	Oil tray
CD679 - Adjustable Salamander Grill	8	AD797	Grilling rack
CD679 - Adjustable Salamander Grill	9	AD798	Element
CD679 - Adjustable Salamander Grill	10	☎	Top casing
CD679 - Adjustable Salamander Grill	11	☎	Rear Casing
CD679 - Adjustable Salamander Grill	12	☎	Horizontal rod assembly
CD679 - Adjustable Salamander Grill	13	☎	Connection assembly
CD679 - Adjustable Salamander Grill	14	☎	Vertical rod assembly
CD679 - Adjustable Salamander Grill	15	☎	Small cable fixing plate
CD679 - Adjustable Salamander Grill	16	☎	Counterweight assembly
CD679 - Adjustable Salamander Grill	17	☎	Rear cover panel
CD679 - Adjustable Salamander Grill	18	☎	Track for guide wheel
CD679 - Adjustable Salamander Grill	19	☎	Upper fixing plate
CD679 - Adjustable Salamander Grill	20	☎	Lower fixing plate
CD679 - Adjustable Salamander Grill	21	☎	Lower short rod assembly
CD679 - Adjustable Salamander Grill	22	☎	Power Cord
CD679 - Adjustable Salamander Grill	23	AC689	Feet

